

Single User guideWELD VR installation Guide

Purpose

This guide will walk you through a single user installation.

Prerequisites

- Computer System
- Administrative Permissions

Steps to Perform Installation

1. Go to <http://www.realityworks.com/guideweldvr-downloads>
2. Download or copy the installation package to the computer
 - a. If you do not have internet access you may have received the guideWELD® VR simulator package on a thumb drive. Copy the installation package to the computer on which you will be installing the software.
3. Launch the installer and follow the prompts to complete the installation. Three programs will automatically install in the background: The guideWELD® VR software, the Database Utility and PostgreSQL.
4. Launch the guideWELD VR application.
5. Select a language choice, then click the Play button.
6. Enter “admin” in the Username field, and “admin” in the Password field. These are the default credentials for the guideWELD VR Administrator.
7. You will be prompted to change the Administrator password. Change the Administrator password to “123abc” or something of your choosing. Follow the prompts to complete this step. After you have changed the default password, the Admin Main screen will be displayed.
 - a. The Admin username and password are stored locally. Administrators should keep this information stored.

For additional assistance and video tutorials visit our website:

www.realityworks.com/support/